


RC100 RECEIVER


RC100

OBSOLETE

TRAN12 Transmitter




TRAN34 Transmitter



Channel Selection

RC100 Receiver



POWER IN 120V AC
HOT
NEUTRAL
GROUND

M

- 1 - 120v-60hz Hot (Black)
- 2 - Neutral Common (White)
- 3 - Ground (Green)
- 4 - Direction 1 (Red)
- 5 - Direction 2 (Black)
- 6 - Common (White)
- 7 & 8 - Remote Override Switch (SPBS)
- * 9 & 10 - Safety Device Connection
- 11 - Coax Antenna Connection (not supplied)
- 12 - Standard Antenna (supplied with unit)
- TL - Run Timer

NOTE: If you are not using a safety device a jumper wire must be connected to terminals 9 & 10. DO NOT CUT ANTENNA WIRE SUPPLIED WITH THIS UNIT.